


CLOSED

OPEN

CLOSED  
SIDE

OPEN  
SIDE




NOTE:

RED is raised WHITE actuator normally open (NO) to number side of switch.

SWE - SWA  
CODE BLOCK 11


OPEN  
SIDE

CLOSED  
SIDE




SWITCH 8:  
G5/GV = OPEN  
JEDI = CLOSED

(Shown in  
JEDI position)



KE Helmet



KA Helmet