

## Installation Information

INTERFACE CABLE CONNECTS TO J3 LOCATED ON THE REAR OF RADIO

TiL DOCUMENT NO. 15RE532 REV. C

READ PAGES 17 & 18

SECTIONS 3.5 & 3.6

FPP SETTINGS:


Ext Spkr - RX ONLY

Ext Vol - SET IntSpkr = 0


Mod Lvl - 1800

Comp Lvl - 400

## RCB-xxTF




**Rear View**  
Technisonic TDAM-1000



26-Pin Accessory Connector

**Front View**  
26-Pin Accessory Connector



18 - PTT  
8 - Speaker +  
9 - Speaker -  
14 - MIC Low  
6 - MIC High  
17 - Ground